




SUITABLE SUBSTRATES

Properly prepped, primed, and OEM grade clear coat to include but not limited to:

- Plastic
- Metal
- Carbon Fiber
- Wood
- Fiberglass

* Conductive substrates must be fully encapsulated so substrate will not get energized



MIXING

- Contents premixed and ready to use
- Thoroughly hand shake before use
- Use ONLY glass or plastic stirrer if needed
- Strain with nylon 120 mesh or 125 microns filter





Premixed




APPLICATION

- Apply 2 wet cross coats
- 50% to 75% overlap
- 20 – 25 psi at nozzle for HVLP
- Constantly agitate material



DRY SCHEDULE

- 5 – 10 minutes flash between coats
- Allow 15 – 30 minutes between layers
- No longer than 8-12 hours between layers
- @ 70 F / 30% humidity



NOTES

Pour remainder material back in original canister after thoroughly agitated

Shelf life: 6 months

Approximate Coverage:

4oz/118ml = 1-2 square feet

8oz/237ml = 3-4 square feet



PERSONAL PROTECTION

- For use by trained professionals only
- Read all labels, directions, and SDS before use
- Use all appropriate Personal Protective Equipment while mixing and spraying